

## INSTALLING EXTRA RAM

As shipped the HT-68k single board computer has 128K of ram installed. To expand the RAM memory on the board plug in additional ram chips. These should be 64k\*4 dynamic rams with an access time of 150nsec or faster. Normal handling precautions should be observed because the memory chips are static sensitive. Be careful to orient the one pin the same as the soldered in memory chips.

No software changes are required. As normally shipped the K-OS ONE operating system uses the top 256k as a RAM disk. This is referenced as disk E. If you do not want the ram disk you can ignore it on the current version of K-OS ONE for the HT-68k.